

KFK

Duct DX cooling units for rectangular air ducts

Features

- Supply air cooling for ventilation systems in various premises.
- Suitable for installation into supply or air handling units to provide air cooling.




Design

- Galvanized steel casing.
- The cooling elements are made of copper tubes and aluminum plates.
- Available in three-coil modifications and rated for operation with R123, R134a, R152a, R404a, R407c, R410a, R507, R12, R22 refrigerants.
- Polypropylene droplet separator and drain pan for condensate drainage and removal included.
- Droplet separator operates efficiently at air flow below 4 m/s.

Mounting

- Only horizontal mounting by means of flanged connection. Condensate drainage must be provided.
- Air filter must be installed upstream of the cooling unit to prevent the unit soiling.
- Mounting position must ensure uniform air flow distribution through the entire cross section.
- Installation upstream or downstream of the supply fan. The minimum air duct length downstream of the fan must be 1 m to ensure air flow stabilization.
- The maximum cooling capacity is attained if the cooling unit is connected on counter-flow basis. The attached charts are valid for counter-flow connection.


- While mounting the cooling unit provide condensate drainage through the U-trap. The U-trap height must be selected with respect to the total fan pressure, refer to the table and diagram below.




H [mm]	K [mm]	P [Pa]
100	55	600
200	105	1100
260	140	1400

H – U-trap height
K – drainage height
P – total fan pressure

- For a proper and safe operation of the cooling unit it should be connected to a control system for integral control and automatic cooling capacity regulation.



Counter air flow connection




Air flow streamwise connection

Designation key

Series	Flange size (WxH) [cm]	Number of water (glycol) coil rows
KFK	40x20; 50x25; 50x30; 60x30; 60x35; 70x40; 80x50; 90x50; 100x50	3


Overall dimensions [mm]

Model	D	D1	B	B1	B2	H	H1	H2	L
KFK 40x20-3	12	22	400	440	470	200	295	103	44
KFK 50x25-3	12	22	500	540	570	250	345	155	44
KFK 50x30-3	12	22	500	540	570	300	395	210	33
KFK 60x30-3	18	28	600	640	670	300	395	199	44
KFK 60x35-3	18	28	600	640	670	350	445	199	44
KFK 70x40-3	22	28	700	740	770	400	495	224	44
KFK 80x50-3	22	28	800	840	870	500	595	340	44
KFK 90x50-3	22	28	900	940	970	500	595	340	44
KFK 100x50-3	22	28	1000	1040	1070	500	595	325	44



KFK



Air pressure losses in DX cooling coils





Water cooling unit calculation diagram

KFK 40x20-3

Air temperature after cooling unit [°C]



Coiling unit capacity [kW]



Refrigerant pressure drop [kPa]

Refrigerant consumption rate [kg/h]

How to use water heater diagrams.

The air flow is 900 m³/h and the air speed in the cooling unit is 3.2 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outdoor summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+20.1 °C) ③.



- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (6.5 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (100 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (6.5 kPa).



COOLERS

KFK 50x25-3

Air temperature after cooling unit [°C]



Coiling unit capacity [kW]



Refrigerant pressure drop [kPa]

Refrigerant consumption rate [kg/h]

How to use water heater diagrams.

The air flow is 1400 m³/h and the air speed in the cooling unit is 3.1 m/s ①.




- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outdoor summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+20 °C) ③.

- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (10.0 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (152 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (7.5 kPa).

KFK 50x30-3

Air temperature after cooling unit [°C]



How to use water heater diagrams.

The air flow is 2000 m³/h and the air speed in the cooling unit is 3.75 m/s ①.




- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+20.6 °C) ③.

- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (13.6 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (215 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (16.0 kPa).

KFK 60x30-3

Air temperature after cooling unit [°C]



How to use water heater diagrams.

The air flow is 2500 m³/h and the air speed in the cooling unit is 3.75 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+20.7 °C) ③.


- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (17.0 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (225 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (17 kPa).

KFK 60x35-3



Air temperature after cooling unit [°C]

15 16 17 18 19 20 21 22 23 24 25



Coiling unit capacity [kW]

3 6 9 12 15 18 21 24 27



How to use water heater diagrams.

The air flow is 2850 m³/h and the air speed in the cooling unit is 3.85 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+20.7 °C) ③.

- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (19.8 kW).



- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (310 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (24.0 kPa).

COOLERS

KFK 70x40-3



Air temperature after cooling unit [°C]

15 16 17 18 19 20 21 22 23 24 25



Coiling unit capacity [kW]

5 10 15 20 25 30 35



How to use water heater diagrams.

The air flow is 4000 m³/h and the air speed in the cooling unit is 4.15 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+19.8 °C) ③.



- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (28.5 kW).

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (360kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (19.0 kPa).

KFK 80x50-3


Air temperature after cooling unit [°C]

15 16 17 18 19 20 21 22 23 24 25



Coiling unit capacity [kW]

5 10 15 20 25 30 35 40 45



How to use water heater diagrams.

The air flow is 6000 m³/h and the air speed in the cooling unit is 4.35 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+19.9 °C) ③.



- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (43 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (605 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (26.0 kPa).

KFK 90x50-3


Air temperature after cooling unit [°C]

15 16 17 18 19 20 21 22 23 24 25



Coiling unit capacity [kW]

5 10 15 20 25 30 35 40 45 50 55



How to use water heater diagrams.


The air flow is 7000 m³/h and the air speed in the cooling unit is 4.4 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+19.7 °C) ③.

- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (47 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (640 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (26.0 kPa).

KFK 100x50-3



How to use water heater diagrams.

The air flow is 7000 m³/h and the air speed in the cooling unit is 4.1 m/s ①.

- To calculate the coldest air temperature find the intersection point of the air flow line ① with the rated outer summer temperature shown in blue line (e.g., +32 °C) and draw the line ② to the left until it crosses the outdoor air humidity curve (e.g. 50 %). From this point draw a vertical line to the supply air temperature downstream of the cooling unit (+19.6 °C) ③.

- To calculate the power of the cooling unit find the intersection point of the air flow ① with the rated summer temperature (e.g., +32 °C) and draw the line ④ to the right until it crosses the air humidity curve (e.g., 50 %). From this point draw a vertical line to the cooling unit power axis (52 kW) ⑤.

- To define the necessary refrigerant flow through the cooling unit drop a perpendicular ⑥ on the axis which corresponds to refrigerant flow through the cooling unit (710 kg/h).
- To define refrigerant pressure drop in the cooling unit find the intersection point of line ⑥ with the pressure drop chart and draw a perpendicular ⑦ to the right until it crosses the refrigerant pressure axis (30.0 kPa).